



Recommendation:

Min. Pipe Size: 30" 2 ³/₈" Schedule 20, Galvanized

1. Set pipe in wall during construction, or, if wall already exists, drill 3" wide hole to recommended min. depth of 8". Use non-shrinking grout to fill hole around pipe for existing wall scenario.
2. Slide Trex post over pipe.
3. Attach Trex post bracket to Trex post.
4. Pour concrete into cavity of Trex post to top of pipe. Be sure concrete is not too wet or it will seep out under Trex post. (Tip: If concrete is already in Trex post cavity, fasten bottom bracket with concrete screws.)
5. Let concrete set before building fence.

